

# Hanging Instructions

## **Woven Wood/Pearl Wood (Natural Materials)**

Material is pre-trimmed, if trimming, it should be dry and table trimmed.

### **Wall preparation**

- Proper wall preparation is essential. Our wallcoverings can be applied to almost any properly prepared wall surface in sound condition. They must be smooth, clean, dry, free of mildew, grease and stains. Apply a stain killing primer if needed.
- Old wallcoverings and calcimine must be removed and enamel surfaces should be dulled by sanding and sealed.
- All surfaces must be properly prepared using a professional latex based primer, such as Roman's R-35. Oil based products should be avoided.
- Adhesive & wallcovering must be room temperature for at least 24 hours (not less than 55° ), prior to and during the installation.
- **Apply adhesive by prepasteing walls before you apply/install wallcovering. Let it dry completely before installing last strip. This will give you good tack for installalation.**

### **Important note for Application**

- Examine material to ensure correct product before cutting. All rolls should be numbered, material must be cut and installed in numeric sequence, lowest to highest.
- Inspect installation after applying no more than three (3) strips. Obtain approval before proceeding. The manufacturer is not responsible for claims beyond the initial three (3) strips.
- Use strips in exact order as they are cut from roll. Fill in over doors and windows as you come to them with strips cut in consecutive order from the roll.
- Paste one piece at a time, soak 5 to 8 minutes then proceed with installation. After 3 panels, examine and inspect material and installation. If at any time, during the installation a discrepancy occurs, stop, contact the designer or manufacturer before proceeding.
- **Use only heavy-duty clear adhesive (premixed) only. Do not use a clear strippable adhesive.**
- **Use a soft brush or smoothing blade of flexible plastic designed for fabrics for smoothing and removing air pockets.**

**Do not use a pasting machine when hanging this product.**

### **Cleaning**

Special care should be taken to avoid any paste from getting on to the face of the material.

If any paste gets on the material, immediately remove with soft moist rag and dry moisture with dry towel.

When wiping this material, there will be a slight residue of the finish coming off. The object is, to due a minimum of wiping so not to change the finish of the product.

**\*\*\*\*\*Take special care not to get anything on the face of material\*\*\*\*\***

# **STOP ATTENTION**

This is a special natural “Wood” Product.

Special care should be taken when installing.

When wiping this material, there will be a slight residue of the finish coming off. The object is, to due a minimum of wiping so not to change the finish of the product.