

# INNOVATIONS

---

## Installation Guidelines for **CHIMERA**

### **WARNING:**

DO NOT CUT OR INSTALL THIS MATERIAL UNTIL YOU HAVE READ THESE INSTRUCTIONS.  
SHOULD A DISCREPANCY OCCUR, CONTACT INNOVATIONS CUSTOMER SERVICE IMMEDIATELY.

### Important Notes Prior to Installation

- Examine your order and corresponding packing list to ensure that you have received the correct product. Please check material for defects prior to installation. **Product claims will not be considered on cut or installed material after (3) three panels have been hung.**
- **There are often slight irregularities in the natural fibers of CHIMERA. This variation is a natural characteristic of this item and it is not considered a defect. Seams may be obvious upon installation.**
- **CHIMERA consists of a large scale pattern measuring 23 1/2" vertically and 35" horizontally. This pattern must be side matched. To side match, use the hash marks printed in the white selvedge of this material.**
- **DO NOT TRIM THE MATERIAL PAST THE 1/2" UNPRINTED SELVEDGE. ONLY TRIM THE UNPRINTED EDGES OF THIS PATTERN OR YOU WILL NOT BE ABLE TO SIDE MATCH THIS MATERIAL.**

### Wall Preparation

- Proper surface prep is key. We recommend hanging product on new sheetrock.
- If new sheetrock is not available, walls must be mirror smooth and free of flaking paint and old adhesive.
- Monitor wall moisture levels. A wall that is not properly prepared or that has too much moisture content may not be conducive to proper adhesion.
- Apply an **acrylic or latex primer/sizer that is made specifically for wallcovering.**

### Important Notes for Application

- We recommend a **heavy duty pre-mixed, clear, non-strippable water-based adhesive** to be used. **Do not dilute the adhesive.**
- **Apply paste with a roller to the back of the paper, allowing paste to become tacky prior to hanging.** Take care not to get adhesive on surface. **Do not use a pasting machine and avoid excessive soaking of material.**
- **Installation location must be climate controlled. Booking time will vary depending on temperature, climate and product backing.**

### Hanging and Trimming of Materials

- **CHIMERA must be table trimmed and butted on the wall using a fresh blade and straight edge with each cut.**
- **CHIMERA is meant to be straight hung, due to its distinct side match pattern.**
- **CHIMERA consists of a large scale pattern measuring 23 1/2" vertically and 35" horizontally. This pattern must be side matched. To side match, use the hash marks printed in the white selvedge of this material.**
- **DO NOT TRIM THE MATERIAL PAST THE 1/2" UNPRINTED SELVEDGE. ONLY TRIM THE UNPRINTED EDGES OF THIS PATTERN OR YOU WILL NOT BE ABLE TO SIDE MATCH THIS MATERIAL.**
- Hang CHIMERA in sequence as cut from bolt. Paste and hang one strip at a time.
- **Use soft bristle brush and wooden or padded roller to carefully apply wallcovering to wall. Do not use a metal knife or stiff sweep.** Avoid over working seams to prevent damage to edges.
- CHIMERA can be wrapped around a corner. Materials will soften once adhesive is applied to back of paper. When wrapping an external corner, be sure to wrap corner by at least 6".