

# INNOVATIONS

---

## Installation Guidelines for **MURANO MOLTO**

### **WARNING:**

DO NOT CUT OR INSTALL THIS MATERIAL UNTIL YOU HAVE READ THESE INSTRUCTIONS.  
SHOULD A DISCREPANCY OCCUR, CONTACT INNOVATIONS CUSTOMER SERVICE IMMEDIATELY.

### **Important Notes Prior to Installation**

- Examine your order and corresponding packing list to ensure that you have received the correct product. Please check material for defects prior to installation. **Product claims will not be considered on cut or installed material after (3) three panels have been hung.**
- **Seams may be obvious upon installation due to MURANO MOLTO's reflective tendency.**

### **Wall Preparation**

- Proper surface prep is key. We recommend hanging product on new sheetrock.
- If new sheetrock is not available, walls must be mirror smooth and free of flaking paint and old adhesive.
- Monitor wall moisture levels. A wall that is not properly prepared or that has too much moisture content may not be conducive to proper adhesion.
- Apply an **acrylic or latex primer/sizer that is made specifically for wallcovering.**

### **Important Notes for Application**

- We recommend a **heavy duty pre-mixed, clear, non-strippable water-based adhesive** to be used. **Do not dilute the adhesive. If you feel you need additional adhesion, you may mix in a small amount of clay or vinyl over vinyl (VOV) adhesive.**
- Apply paste with roller to ensure even application, taking care not to get adhesive on surface. **Do not use a pasting machine and avoid excessive soaking of material.**
- **Installation location must be climate controlled. Booking time will vary depending on temperature, climate and product backing.**

### **Hanging and Trimming of Materials**

- **Table trimming is recommended for MURANO MOLTO.** MURANO MOLTO should be trimmed from the back of the material with a new blade and straight edge.
- **Due to its metallic nature, MURANO MOLTO is recommended to be hung straight.**
- Hang MURANO MOLTO in sequence as cut from bolt. Paste and hang one strip at a time.
- Smooth material to the hanging surface with a soft bristle brush to ensure good adhesion. A rubber seam roller is recommended for all seams. Avoid over working seams to prevent damage to edges.
- MURANO MOLTO can be installed in both inside and outside corners. Create a template for corners that are not square.