

Installation Guidelines for **ARBORESQUE**

WARNING:

DO NOT CUT OR INSTALL THIS MATERIAL UNTIL YOU HAVE READ THESE INSTRUCTIONS.
SHOULD A DISCREPANCY OCCUR, CONTACT INNOVATIONS CUSTOMER SERVICE IMMEDIATELY.

Important Notes Prior to Installation

- Examine your order and corresponding packing list to ensure that you have received the correct product. Please check material for defects prior to installation. **Product claims will not be considered on cut or installed material after (3) three panels have been hung.**
- **There are often slight irregularities in the natural fibers of ARBORESQUE. This variation is a natural characteristic of this item and it is not considered a defect. Seams may be obvious upon installation.**
- **ARBORESQUE consists of a large scale pattern measuring 36" vertically and 36" horizontally. This pattern must be side matched. To side match, use the hash marks printed in the white selvage of this material.**
- **DO NOT TRIM THE MATERIAL PAST THE ½" UNPRINTED SELVEDGE. ONLY TRIM THE UNPRINTED EDGES OF THIS PATTERN OR YOU WILL NOT BE ABLE TO SIDE MATCH THIS MATERIAL.**

Wall Preparation

- Proper surface prep is key. We recommend hanging product on new sheetrock.
- If new sheetrock is not available, walls must be mirror smooth and free of flaking paint and old adhesive.
- Monitor wall moisture levels. A wall that is not properly prepared or that has too much moisture content may not be conducive to proper adhesion.
- Apply an acrylic or latex primer/sizer that is made specifically for wallcovering.

Important Notes for Application

- We recommend a heavy duty pre-mixed, clear, non-strippable water-based adhesive to be used. **Do not dilute the adhesive.**
- Apply paste with a roller to the back of the paper, allowing paste to become tacky prior to hanging. Take care not to get adhesive on surface. **Do not use a pasting machine and avoid excessive soaking of material.**
- **Installation location must be climate controlled. Booking time will vary depending on temperature, climate and product backing.**

Hanging and Trimming of Materials

- **ARBORESQUE must be table trimmed and butted on the wall using a fresh blade and straight edge with each cut.**
- **ARBORESQUE is meant to be straight hung, due to its distinct side match pattern.**
- **ARBORESQUE consists of a large scale pattern measuring 36" vertically and 36" horizontally. This pattern must be side matched. To side match, use the hash marks printed in the white selvage of this material.**
- **DO NOT TRIM THE MATERIAL PAST THE ½" UNPRINTED SELVEDGE. ONLY TRIM THE UNPRINTED EDGES OF THIS PATTERN OR YOU WILL NOT BE ABLE TO SIDE MATCH THIS MATERIAL.**
- Hang ARBORESQUE in sequence as cut from bolt. Paste and hang one strip at a time.
- **Use soft bristle brush and wooden or padded roller to carefully apply wallcovering to wall. Do not use a metal knife or stiff sweep.** Avoid over working seams to prevent damage to edges.
- ARBORESQUE can be wrapped around a corner. Materials will soften once adhesive is applied to back of paper. When wrapping an external corner, be sure to wrap corner by at least 6".

INNOVATIONS

ARBORESQUE Line Drawing

