

# INNOVATIONS®

THANK YOU for your purchase of Innovations! Below are our hanging instructions, intended to help you accomplish a beautiful installation. Before proceeding with your installation, check your material and packing slip to ensure you've received your order in entirety. Also check for signs of defects prior to installation of material. If at any time you have questions regarding your installation, please call our offices at 800.227.8053.

Please note that Innovations is unable to entertain product claims after three (3) panels have been hung or if material is cut and glued in excess of three (3) drops.

**Pattern:** Calico

**Recommended Primer:** Pigmented Acrylic Wallcovering Specific Primer like tinted pigmented Shieldz® Universal **White** Primer. Wall should then be sized with a non-strippable, heavy duty, clear adhesive like Romans 838 and allowed to dry.

**Recommended Adhesive:** Non-strippable, heavy duty, clear adhesive like Romans 838. Wall should be sized with a non-strippable, heavy duty, clear adhesive like Romans 838 and allowed to dry.

**Recommended Wall Surface:** Level 4 sheetrock finish or similar

**Seams/Paneling Visibility:** Seamless with no Paneling

**Hanging Directionality:** Straight Hang

**Pattern Matching:** Side match the motif, see diagram below

**Trimming/Hanging Method:** Material is pretrimmed but can be table trimmed and butt seamed

**Recommended Smoother/Roller:** Plastic Smoother and Rubber Seam Roller

**Wrapping Corners:** Creasing at the material to wrap the corner is not recommended. It is best if the material is flush cut and overlapped at the corner, similar to adhering a veneer on a cabinet door.

1. Begin installation by inspecting the material you have received. Ensure all material is visually defect free and matches packing slip.
2. Using correct wallcovering primer, apply primer to destination wall and allow primer to dry.
3. Wall should then be sized with a non-strippable, heavy duty, clear adhesive like Romans 838 and allowed to dry.
  - a. Always make sure your installation location is properly climate controlled.
4. Apply paste to backing of material using an adhesive roller. Avoid oversaking and ensure even application. DO NOT USE a pasting machine as it will add too much water content to paste.
5. Once material has properly been booked to ensure proper level of tack, apply material to the primed wall.
  - a. Hang material in sequence as it comes off the roll, including short drops around windows, doors, and other obstructions on your wall.
6. DO NOT get adhesive on the face of material. Adhesive is very difficult to clean and next to impossible to remove after it is dry without potentially damaging the wallcovering face. Dried adhesive also tends to leave a hazy appearance.
  - a. To avoid getting adhesive on the face of material, we recommend using a low-adhesive safe-release painter's tape on the seams to keep the product face clean.
7. When trimming this product, we advise you to use a new razor blade with each cut. A dull razor blade is the primary cause of fraying and unsightly seams. DO NOT USE a seam buster.

## Pattern Notes:

- Calico is pretrimmed however it can be table trimmed and butt seamed should the wall need to be panelized in equal widths. Expect to trim 1/16" should the material need to be trimmed.

# INNOVATIONS®

Calico Installation:



Repeat Diagram:

